




# VTech CS6719-2 Base Fuse Replacement

This is a guide to replace the the fuse on the circuit board located inside the main base of the Vtech CS67192

Written By: Nick Boyd



## INTRODUCTION

During this guide, the base will need to be disassembled and flip the board over to de-solder the fuse connection.


---



### TOOLS:


- [Soldering Station](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
  - [Heavy-Duty Spudger](#) (1)
-

## Step 1 — Base



- Remove the four Phillips #0 screws (9.4mm) located at the bottom of the phone on the back side of the base.


## Step 2



- Use the spudger to separate the bottom from the top.
- ⓘ There are two clips, located top and bottom, that you have to compress with the spudger.




## Step 3 — Base Fuse



- Locate the Fuse


## Step 4



- Flip the board over


**i** Note: Remember where the fuse is located

## Step 5



- Refer to the guide on [How To Solder and Desolder Connections](#)

## Step 6



- Flip board back over and remove the fuse.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 06:37:18 AM.